

FOREWORD

This document is for control room personnel who operate the 3300 Monitoring System. The procedures are presented in step-by-step graphic format.

RELATED DOCUMENTS

3300 System Overview, 80177

3300 System Installation Instructions, 80172

3300 System Troubleshooting, 80173

3300/10 Power Supply, 80174

3300/01 System Monitor, 80175

3300/48 Case Expansion Maintenance, 84418-01

Dynamic Data Manager System, 46390-01

Keyphasor® is a registered trademark of Bently Nevada Corporation

Proximitor® is a registered trademark of Bently Nevada Corporation

Document No. 84417 ■ First Printing: April 1989 ■ Revision NC: April 1989

Copyright© 1989 Bently Nevada Corporation

All Rights reserved

No Part of this publication may be reproduced, transmitted, stored in a retrieval system nor translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of the copyright owner,

Bently Nevada Corporation
P.O. Box 157
Minden, Nevada 89423 USA
Telephone 800-227-5514 702-782-3611
Telemail/Telex 7400983 BNC UC
Fax 702-782-9253
Copyright infringement is a serious matter under
United States of America and Foreign Copyright Laws

2

MONITOR OPTIONS

CASE EXPANSION
MONITOR PART NUMBER

FULL SCALE RANGE	TRANSDUCER INPUT	ALARM RELAY	AGENCY APPROVAL
3300/48	AA	BB	CC DD
01 = 0 - 1.0 inches 02 = 0 - 25 mm 03 = 0 - 2 inches 04 = 0 - 50 mm 05 = 0 - 4 inches 06 = 0 - 100 mm	01 = 1 inch LVDT (9 V/inch) 02 = 2 inch LVDT (10 V/inch) 03 = 4 inch LVDT (3.5 V/inch)	00 = NONE 01 = EPOXY SEALED 02 = HERMETI- CALLY	00 = NOT REQUIRED 01 = CSA 02 = BASEEFA 03 = FM


9

READ SETPOINT LEVELS

Note: You can read the setpoints in Differential Mode only. If you try to read the setpoints in direct mode, the display will be blank.

Alert SetPoint = 0.4 inches

Danger SetPoint = 0.6 inches



10


SELF TESTS

The three levels of self tests are

power-up - performed only when the monitor is turned on

cyclic - continuously performed by the monitor

user-invoked - performed only when initiated by the user.



The monitor on this page is giving a signal that a continuing error has been detected during a self test. When a continuing error is detected,

monitoring is stopped until the error is resolved,

the error code is flashed on the LCD bar graph and stored in memory,


the Bypass LED comes on and the OK LED flashes at 5 Hz.

If the error goes away, monitoring is resumed and the OK LEDs flash at 5 Hz. The error code, however, remains stored in the monitor and may be read by using the user-invoked self test.

Note:

Although both columns of the bar graph flash, the error code is only the sum of the bar graph segments displayed in one column. For example the monitor on this page is displaying error code 6.

10 SELF TESTS



Error Code	Description
2	ROM CHECKSUM has failed. *
3	EEPROM failure number 1. **
4	EEPROM failure number 2. *** Adjust set points
5	+7.5V/-VT node out of tolerance. **
6	+VRH node out of tolerance. **
7	+5V node out of tolerance. **
8	MVREF node out of tolerance. **
9	+7.5V node out of tolerance. **
10	+VRL node out of tolerance. **
12	+5V/-7.5V node out of tolerance. **
14	RAM failure. *
17	COP Watchdog not configured.
18	+5V/-5V or +15V node out of tolerance. **
21	Incorrect switch or switch combination. ****
22	Incorrect jumper configuration. *

* Tested only at Power Up or User Invoked Self Test. This error is displayed on the front panel but is not stored in memory.

** Tested only at Cyclic Self Test. Errors 2, 3, and 14 are non-recoverable and errors 5 through 13 could be intermittent and recoverable.


*** Error 4 is a setpoint failure and may be corrected by adjusting all setpoints in the monitor.

**** Tested only when monitor is in calibration mode.

3300/48
CASE EXPANSION
MONITOR

MAINTENANCE MANUAL

**BENTLY
NEVADA** 



FORWARD

This document is intended for personnel who maintain the 3300 Monitoring System. The procedures are presented in step-by-step graphic format.

RELATED DOCUMENTS

3300 System Overview, 80177

3300 System Installation Instructions, 80172

3300 System Troubleshooting, 80173

3300/10 Power Supply, 80174

3300/01 System Monitor, 80175

3300/48 Case Expansion Operation, 84417-01

Dynamic Data Manager System, 46390-01

Keyphasor® is a registered trademark of Bently Nevada Corporation

Proximitr® is a registered trademark of Bently Nevada Corporation

Document No. 84418 ■ First Printing: April 1989 ■ Revision A: December 1989

Copyright© 1989 Bently Nevada Corporation

All Rights reserved

No Part of this publication may be reproduced, transmitted, stored in a retrieval system nor translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of the copyright owner.

Bently Nevada Corporation
P.O. Box 157
Minden, Nevada 89423 USA
Telephone 800-227-5514 702-782-3611
Telemail/Telex 7400983 BNC UC
Fax 702-782-9253

Copyright infringement is a serious matter under
United States of America and Foreign Copyright Laws


6 MONITOR OPTIONS**CASE EXPANSION
MONITOR PART NUMBER**

FULL SCALE RANGE	TRANSDUCER INPUT	ALARM RELAY	AGENCY APPROVAL																								
3300/48 ————— AA ————— BB ————— CC ————— DD	<table><tr><td>01 = 0 - 1.0 inches</td><td>01 = 1 inch LVDT (9 V/inch)</td><td>00 = NONE</td><td>00 = NOT REQUIRED</td></tr><tr><td>02 = 0 - 25 mm</td><td>02 = 2 inch LVDT (10 V/inch)</td><td>01 = EPOXY SEALED</td><td>01 = CSA</td></tr><tr><td>03 = 0 - 2 inches</td><td>03 = 4 inch LVDT (3.5 V/inch)</td><td>02 = HERMETI- CALLY</td><td>02 = BASEEFA</td></tr><tr><td>04 = 0 - 50 mm</td><td></td><td></td><td>03 = FM</td></tr><tr><td>05 = 0 - 4 inches</td><td></td><td></td><td></td></tr><tr><td>06 = 0 - 100 mm</td><td></td><td></td><td></td></tr></table>	01 = 0 - 1.0 inches	01 = 1 inch LVDT (9 V/inch)	00 = NONE	00 = NOT REQUIRED	02 = 0 - 25 mm	02 = 2 inch LVDT (10 V/inch)	01 = EPOXY SEALED	01 = CSA	03 = 0 - 2 inches	03 = 4 inch LVDT (3.5 V/inch)	02 = HERMETI- CALLY	02 = BASEEFA	04 = 0 - 50 mm			03 = FM	05 = 0 - 4 inches				06 = 0 - 100 mm					
01 = 0 - 1.0 inches	01 = 1 inch LVDT (9 V/inch)	00 = NONE	00 = NOT REQUIRED																								
02 = 0 - 25 mm	02 = 2 inch LVDT (10 V/inch)	01 = EPOXY SEALED	01 = CSA																								
03 = 0 - 2 inches	03 = 4 inch LVDT (3.5 V/inch)	02 = HERMETI- CALLY	02 = BASEEFA																								
04 = 0 - 50 mm			03 = FM																								
05 = 0 - 4 inches																											
06 = 0 - 100 mm																											

14 Self Test

The three levels of self tests are

- power-up - performed only when the monitor is turned on
- cyclic - continuously performed by the monitor
- user-invoked - performed only when initiated by the user.



The monitor on this page is giving a signal that a continuing error has been detected during a self test. When a continuing error is detected,


monitoring is stopped until the error is resolved,

the error code is flashed on the LCD bar graph and stored in memory,

the Bypass LED comes on and the OK LED flashes at 5 Hz.

If the error goes away, monitoring is resumed and the OK LEDs flash at 5 Hz. The error code, however, remains stored in the monitor and may be read by using the user-invoked self test.

14 Self Test [Cont]



Error Code	Description
2	ROM CHECKSUM has failed. *
3	EEPROM failure number 1. **
4	EEPROM failure number 2. *** Adjust set points
5	+7.5V/-VT node out of tolerance. **
6	+VRH node out of tolerance. **
7	+5V node out of tolerance. **
8	MVREF node out of tolerance. **
9	+7.5V node out of tolerance. **
10	+VRL node out of tolerance. **
12	+5V/-7.5V node out of tolerance. **
14	RAM failure. *
17	COP Watchdog not configured.
18	+5V/-5V or +15V node out of tolerance. **
21	Incorrect switch or switch combination. ****
22	Incorrect jumper configuration. *

* Tested only at Power Up or User Invoked Self Test. This error is displayed on the front panel but is not stored in memory.

** Tested only at Cyclic Self Test. Errors 2, 3, and 14 are non-recoverable and errors 5 through 13 could be intermittent and recoverable.

*** Error 4 is a setpoint failure and may be corrected by adjusting all setpoints in the monitor.

**** Tested only when monitor is in calibration mode.